



## **Long Term Shutdown Advisory**

---

It is highly recommended that DTS / DTG printers that will not be operational for more than 3 weeks, be filled with cleaning solution to avoid potential ink drying in nozzles. It is critical that the equipment is properly cleaned prior to capping and powering equipment off for storage. Please take your time following all necessary procedures:

**DS4000 / 2000 / 1500** printers for storage less than 3 weeks, use document:

- DS4000 3 - Weeks Shutdown Procedure.pdf

**DS4000 / 2000 / 1500** printers for storage more than 3 weeks, use document:

- DS4000 3+ weeks Shutdown with cleaning.pdf

**Maverick** printers for storage for more than 3 weeks, use document:

Maverick\_LONG TERM Shutdown Procedure.pdf

**I-image S** printers for storage more than 3 weeks:

Put printer on cleaning solution. Cap the print head. Close top valves. Power off the unit. Use this document as guideline:

- I-IMAGE S PURGE DOCUMENT.pdf

**I-image ST/STE/1/2** printers for storage more than 3 weeks:

Put printer on cleaning solution. Cap the print head. Close top valves. Power off the unit.

Use this document as guideline:

- I-IMAGE ST,STE,1,2 PURGE DOCUMENT.pdf

**M-Link / M-linkX** printers for storage more than 3 weeks:

Put printer on cleaning solution. Verify purge tubes are filled with cleaning solution. Add storage solution to caps. Cap the print head. Close top valves. Power off the unit.

Use these documents as guideline:

- MLINK PURGE DOCUMENT.pdf
- MLINK DAILY SHUT DOWN DOCUMENT.pdf